

<b>Cisco</b>	<b>PXE 가</b> .....	3
	.....	3



# Cisco

# PXE

# 가

Cisco

PXE 가

가

1. exec

```
Router(config)#no spanning-tree
```

2. Portfast - Portfast /  
Cisco /  
Portfast 가

```
Switch>enable Switch#configure terminal Switch(config)#spanning-tree portfast default
```

```
###  
Switch#show spanning-tree interface GigabitEthernet 0/48 portfast
```

- [https://docs.oracle.com/cd/E50698\\_01/html/E50059/glzbnk.html](https://docs.oracle.com/cd/E50698_01/html/E50059/glzbnk.html)
- <https://www.rcannings.com/cannot-pxe-boot-on-an-interface-with-spanning-tree-portfast-disable-d/>
- <https://networkguy.de/spanning-tree-protocol-and-pxe-boot/>

From: <https://atl.kr/dokuwiki/> - AllThatLinux!  
 Permanent link: [https://atl.kr/dokuwiki/doku.php/cisco\\_%EC%8A%A4%EC%9C%84%EC%B9%98%EB%A5%BC\\_%EC%82%AC%EC%9A%A9%ED%95%A0\\_%EB%95%8C\\_pxe\\_%EB%B6%80%ED%8A%B8%EA%B0%80\\_%EC%8B%A4%ED%8C%A8%ED%95%A8](https://atl.kr/dokuwiki/doku.php/cisco_%EC%8A%A4%EC%9C%84%EC%B9%98%EB%A5%BC_%EC%82%AC%EC%9A%A9%ED%95%A0_%EB%95%8C_pxe_%EB%B6%80%ED%8A%B8%EA%B0%80_%EC%8B%A4%ED%8C%A8%ED%95%A8)  
 Last update: 2022/02/24 02:25

