

Cisco	PXE 가	3
	3

Cisco

PXE

가

Cisco PXE 가 . 가

1. exec .

```
Router(config)#no spanning-tree
```

2. Portfast . - Portfast /
/ / Cisco
. Portfast 가

```
Switch>enable Switch#configure terminal Switch(config)#spanning-tree portfast default
```

###

```
Switch#show spanning-tree interface GigabitEthernet 0/48 portfast
```

- https://docs.oracle.com/cd/E50698_01/html/E50059/glzbk.html
- <https://www.rcannings.com/cannot-pxe-boot-on-an-interface-with-spanning-tree-portfast-disable/>
- <https://networkguy.de/spanning-tree-protocol-and-pxe-boot/>

From:
<https://atl.kr/dokuwiki/> - AllThatLinux!
 Permanent link:
https://atl.kr/dokuwiki/doku.php/cisco_%EC%8A%A4%EC%9C%84%EC%B9%98%EB%A5%BC_%EC%82%AC%EC%9A%A9%ED%95%A0_%EB%95%8C_pxe_%EB%B6%80%ED%8A%B8%EA%B0%80_%EC%8B%A4%ED%8C%A8%ED%95%A8?rev=1645669489
 Last update: 2022/02/24 02:24

