

Cisco Switch 3

ROMMON Mode 3

 3

 3

IP 4

Timestamp 4

 4

CISCO 5

 5

DNS 7

 7

Cisco Switch

: <https://cdn.technet24.ir/Downloads/Cisco/IOS/>

ROMMON Mode

```

Rommon mode
mode
rommon mode
가          BAUD RATE

```

```

switch: set BAUD 115200
//
switch: set
BAUD=115200
...

```

```

erase start
VLAN 가
vlan.dat delete vlan.dat
reload
no

```

```

#del vlan.dat
#erase start
#reload
no

```

```

switch#>show version //
switch#>show interface vlan //
switch#>show running-config //

```

```

R1# show flash -> Flash
R1# show ip route ->
R1# show ip interface brief ->
R1# show interface [Interface Name] ->
R1# show controllers [Interface Name] ->

```

```

R1# show cdp neighbor ->
R1# show cdp neighbor detail -> IP
R1# show running-config -> Running-Config (RAM)
R1# show startup-config -> Startup-Config (NVRAM)
R1# copy running-config startup-config -> RAM NVRAM
R1# erase startup-config -> NVRAM

```

IP

```

Switch# configure terminal
Switch(config)# interface vlan 1
Switch(config-if)# ip address 192.168.1.2 255.255.255.0
Switch(config-if)# no shutdown
Switch(config-if)# exit
Switch(config)# ip default-gateway 192.168.1.1

```

```

DHCP          1.          interface vlan 1          VLAN 1
. 2. ip address dhcp          IP          . 3. no shutdown
VLAN 1 가          . 4
.
가          dhcp IP          show running-config          IP
.          show dhcp lease          show interface vlan 1          IP
.

```

Timestamp

```

# conf t
(config) # service timestamps debug datetime localtime // debug
(config) # service timestamps log datetime localtime // log

```

```

# sh clock //
# clock set 13:13:13 april 20 2020 //
# clock timezone kst 9 // ( )

# conf t
(config) # ntp server time.bora.net // NTP (boranet)
# sh ntp status // NTP

```

CISCO

- DTP Trunk
- VLAN

•

가

```
gmate(config)# line 0 16
gmate(config-line)# logg sync
```

•

```
gmate(config)#line console 0
gmate(config-line)# exec-timeout 0
```

•

```
gmate(config)# enable secret switch
```

switch

•

```
gmate#show line
```

VTY

```
gmate(config)#line vty 0 15
gmate(config-line)# password switch
```

0~ 15

가 switch

•

```
gmate#show runnign-config
```

- vty

```
gmate(config)#service password-encryption
```

-

```
gmate(config)#banner motd *  
Authonized access only!!  
*
```

*

-

```
gmate(config)# default-value exec-character-bits 8  
gmate(config)# banner motd *  
가 !!  
*  
gmate(config)#
```

-

```
gmate(config)# interface f 1/0/1  
gmate(config)# description gmatel  
gmate(config)# interface f 1/0/2  
gmate(config)# description gmate2
```

-

```
enable  
config terminal  
no ip domain-lookup  
enable secret $gm@te2oo8  
  
alias exec c config terminal  
alias exec r show running-config  
alias exec i show ip route  
alias exec b show ip interface breif  
  
line consol 0  
logging synch  
exec-timeout 0  
lin vty 0 5  
pass $gm@te2oo8
```

```
exit
hostname
```

DNS

```
cisco(config)#
cisco(config)#ip domain-lookup
cisco(config)#ip name-server 210.20.64.21
```

-

```
cisco(config)# no ip domain-lookup
```

- stp

```
Switch# show spanning-tree
Switch# show spanning-tree vlan [num]
Switch# show spanning-tree vlan [num] detail
```

-

```
Switch# show interface status
```

- link aggregation

```
Switch(config)# int port-channel 1
Switch(config-if)# int range gi 1/0/5-6
// chnnel-group 1 mode on
channel-group 1 mode active

Switch(config-if)# channel-proto lacp
Switch(config-if)# exit

Switch(config)# int port-channel 1
Switch(config-if)# switchport mode access
Switch(config-if)# switchport access vlan 10

Switch# show lacp neighbor
```

From:

<https://atl.kr/dokuwiki/> - **AllThatLinux!**

Permanent link:

https://atl.kr/dokuwiki/doku.php/cisco_switch_%EC%84%A4%EC%A0%95?rev=1671612332

Last update: **2022/12/21 08:45**

